

LDM145 Userguide

Product Ovierview

The LDM45 is a CW laser diode module capable of emitting lines of different lengths and a variety of shapes and patterns using interchangeable projection optics. It emits an optional circular or elliptical beam that can be converted into lines, crosses, circles, grids, viewfinders, dot arrays, and more.

An innovative approach to structured illumination, you can easily interchange line-generating optics (LGO) and diffractive optical elements (DOE) by hand. The resulting projections can be used to align, position, and target objects of different shapes and surface profiles.

Wavelengths of green (520nm), red (635, 650, 670nm), and infrared (780, 850nm) are available with output powers up to 5mW. The green model emits light that appears more than 2X brighter to the human eye than the equivalent power in 635nm. As a result, you're more likely to see these projections against dark materials, in high ambient light levels, or from long distances.

Housed in an electrically-isolated and ruggedised metallic body measuring 16mm in diameter, the LDM145 is recommended for industrial environments and integration with OEM equipment.



Product Operation

To operate the laser in CW mode the Red & Black leads should be connected to the following:

	Green Models	Red Models
Red Lead	+10Vdc ± 5%	+3.5 to 5 Vdc
Black Lead	0 Vdc	0 Vdc

Focus Adjustment

The focus of the LDM145 can adjusted using the following method.

- 1. Remove the LGO if fitted
- 2. Insert focus key (see drawing C) into laser barrel and align with focus control groves
- 3. Turn the focus key until desired focus is achieved
- 4. Re-fit the LGO if fitted

Fitting the LGO

Optional line-generating optics (LGO) and diffractive optical elements (DOE) simply fit over the aperture end of the LDM145 and convert the output beam into a line, shape, or pattern. LGOs are available with fan angles from 15° to 120°. DOEs that produce circles, concentric rings, dotted patterns, crosses, multiple parallel lines, grids, viewfinders, and other patterns are also available.

Please follow the below instructions to install the LDM145 with an LGO or DOE:

- 1. Focus the laser at the required distance.
- 2. Using the supplied Allen key, ensure that the two grub screws in the LGO/DOE are flush with the inner bore.
- 3. Slide the LGO/DOE over the aperture side of the laser and rotate until the brightest & thinnest lines or dots are achieved.
- 4. Tighten the two grub screws with the Allen key to lock the LGO/DOE into position.

For more information please see the Projection Lens Datasheet.

Mounting & Heatsinking

The lifetime and stability of your laser can be optimised when mounted on a suitable heat sink. This allows the case temperature to be kept within its specified range. Failure to properly heat sink your laser device could result in shortened lifetime or failure of the diode. As a general guideline, the lifetime of a laser diode decreases by a factor of two (approx.) for every 10°C increase in operating temperature.

There is one mounting clamps available for the LDM145 which is the heavy duty clamp (with/without magnetic base).

Mounting the LDM145 in the Heavy Duty Clamp (See drawing D)

- 1. Secure the clamp to a surface. There are two methods:
- a. Screw an M5 stud to the bottom of the base, or
- b. Remove the base by removing 2 x grub screw B with the supplied Allen key, then thread an M5 cap screw through the top of the base. Then re-attach the base to the body of the clamp.
- 2. Loosen Allen screw A with the supplied Allen key
- 3. Slide your laser into the mounting hole and then tighten Allen screw A
- 4. Loosen grub screw A
- 5. Adjust the vertical angle of your laser and then tighten grub screw A
- 6. Loosen 2 x grub screw B. This will allow the main body of the mount to be rotated independently of the base
- 7. Adjust the horizontal angle of your laser and then tighten 2 x grub screw B

Mounting the LDM145 in the Heavy Duty Clamp with Magnetic Base (See drawing D & E)

- 1. Secure the magnetic base to the Heavy Duty Clamp
- a. Screw the stud on the top of the magnetic base into the centre hole at the bottom of the Heavy Duty Clamp
- 2. Remove the keeper from the magnetic base and place on a ferrous surface
- 3. Loosen Allen screw A with the supplied Allen key
- 4. Slide your laser into the mounting hole and then tighten Allen screw A
- 5. Loosen grub screw A
- 6. Adjust the vertical angle of your laser and then tighten grub screw A
- 7. Loosen 2 x grub screw B. This will allow the main body of the mount to be rotated independently of the base
- 8. Adjust the horizontal angle of your laser and then tighten 2 x grub screw B

Cleaning the Optics

Please place the protective cap over the aperture when the laser is not in use to reduce optical contamination. If the laser pattern becomes fuzzy or unclear, please check the following:

- 1. Remove LGO/DOE
- a. LGOs can be cleaned with an optical cloth, lens cleaning kit, or sterile dry air/nitrogen.
- b. DOEs should only be cleaned with sterile dry air or nitrogen. The use of any other cleaning methods will damage the grating.
- 2. Check the laser is in focus
- 3. The collimating lens inside the laser barrel can be cleaned with dry air

Safety & Classification

These modules are intended for incorporation into customer equipment. They are classified in accordance with IEC60825-1: 2014, which should be consulted prior to designing or using any laser product. The following labels are supplied for attachment to the customer's equipment, but responsibility for compliance with the standard remains with the user.



Class 2 Laser Label



Class 3R Laser Label




Class 3B Laser Label




Class 3B IR Laser Label

Diagrams


A) LDM145 Outline



B) LDM145 Fitted With LGO Outline



C) Focus Key



D) Heavy Duty Mounting Clamp 25mm ø www. www. M5 Mounting hole on base

FRONT VIEW M6 St. Ø35.00

Drawings are not to scale.

Please Note: Global Laser reserve the right to change descriptions and specifications without notice.





T: +44 (0)1495 212213 F:+44 (0)1495 214004 E: sales@globallasertech.com www.globallasertech.com

Global Laser Ltd Units 9-10 Roseheyworth Business Park Abertillery. Gwent NP13 1SP UK